


RS-CV1

Your purchased chain is either a unit length (3048 mm) or a reel. The following tools are available for cutting the chain to a desired length. See "Roller Chain and Sprocket Handling" for use.

1 Chain Vice





RS-CV3

RS-CR1 to RS-CR3

RS-CV2

Model Number	Applicable Chain				Dimensions			
	Single-strand	Double-strand	Triple-strand	L	Н	В		
RS-CR1	RS15	20-00		50	16.4	20		
RS-CR2	RS25	(<u>)</u>	<u> </u>	50	19	20		
RS-CR3	RS35	3 7 - 		60	30	30		
RS-CV1	RS40 - 80	RS40	<u> 1997</u>	100	65	94 - 115		
RS-CV2	RS40 - 160	RS40 - 100	RS40 - 100	180	110	120 - 151		
RS-CV3	RS80 - 240	RS80 - 160	RS80 - 100	200	170	180 - 220		

2 Punch

Primary punch

Secondary punch

М	Applicable Chair					
Primary punch	L Secondary punch L		L	Applicable Chain		
		RS-P21	65	RS15		
RS-P11	52	RS-P22	70	RS25		
		RS-P23	80	RS35		
RS-P14	60	RS-P24	80	RS40 - 60		
RS-P15	70	RS-P25	90	RS80 - 120		
RS-P16	80	RS-P26	120	RS140 - 240		

Note: 1. The RS-P11 can be used with three sizes: RS15, RS25, and RS35.

Model Number					
Rivet punch	L	Applicable Chain			
RS-RPO1	100	RS40			
RS-RPO2	100	RS50			
RS-RPO3	100	RS60			
RS-RPO4	100	RS80			



3 Chain Breakers





F	RS-CS-	A	RS-CS-B	RS-CS-C		
Model Number	L	Applicable Chain (Single-strand)	Model Number	L	Applicable Chain (Single-strand & Double-strand)	
RS-CS-A1	116	R\$25	RS-CS-B1	185	RS40 - 60	
RS-CS-A2	119	RS35	RS-CS-C1	222	RS80, 100	
RS-CS-A3	119	RS41	RS-CS-C2	290	RS120, 140	
RS-CS-A4	119	RF06B	RS-CS-C3	708	RS160 - 240	

Note: In addition to RS Roller Chains, Chain Breakers can be used with BS Roller Chains and Marine Chains. However, Chain Breakers for Marine Chains are made-to-order.

Chain Cutting & Connecting Tools

- Ordering Specify the code (product code and model)
 - Order placement

Product codeModel numberQtyUnitD210013RS-CR11K

4 Poly Steel Chain Cutting Tools


Standard chain cutting tools cannot be used on Poly Steel Chains. A special punch and vice for Poly Steel Chains are required.

Chain L vice	Model Number	L	н	В	Q	Applicable Chain
1	RS-PC01-AST	35	20	20	52	RS25-PC-1
	RS-PC02-AST	50	30	30	52	RS35-PC-1
	RS-PC03-AST	65	35	35	56	RS40-PC-1
B	RS-PC04-AST	80	40	35	56	R\$50-PC-1
5 States	RS-PC05-AST	100	45	40	56	R\$60-PC-1

5 Lambda Chain Cutting Tools

A special vice and a primary and secondary punch are required to disassemble Lambda Chains.

<Cutting Tools>



Model Number	L	н	В	Applicable Chain	
RS-LMD01-AST	65	32	32	RS40-IMD-1	
RS-LMD02-AST	80	40	40	RS50-IMD-1	
RS-LMD03-AST	95	48	48	RS60-IMD-1	
RS-LMD04-AST	130	60	60	RS80-LMD-1	
RS-LMD05-AST	160	73	73	RS100-LMD-1	
RS-LMD06-AST	160	88	88	RS120-LMD-1	
RS-LMD07-AST	180	98	98	RS140-LMD-1	

Note: 1. The special punch and vice are included as a set. Punch dimensions are the same as for the punch in section 2.

Chain Connecting Tool

1 Chain Puller

This tool pulls the two ends of the chain together when installing the chain on a machine.

